



CROSBY


Descriptions

Product code	C576M46
Product description	CROSBY Footrest wood teak Round footstool in solid munggur wood.
Origin country	ID

Dimensions

Height x Width x Depth (cm)	44 cm	x	30 cm	x	30 cm
Product weight (kg)	3,5 Kg				
Seat height (cm)	44				
Seat width (cm)	30				
Seat depth (cm)	30				
Armrest height (cm)					
Armrest width (cm)					
Backrest height (cm)					

Technical drawings



Features

Use (domestic/contract/office)	Domestic
Indoor (yes/no)	Yes
Alfresco (yes/no)	Yes
Outdoor (yes/no)	No
Stackable (yes/no)	No
Stacks up to	
Max. load (kg)	90
Adjustable height (yes/no)	No
Adjustable height mechanism description	N/A

Foldable (yes/no)	No
Swivel (yes/no)	No
Reclining (yes/no)	No
Armrest included (yes/no)	No
Padded (yes/no)	No
Footrest included (yes/no)	No
Fabric durability resistance (Martindale cycles)	
Water repellent (yes/no)	N/A
Stain resistant (yes/no)	N/A
Fire resistant (yes/no)	N/A
UV resistance level (1-5)	
Removable chair cover (yes/no)	No
Removable cover parts description	N/A
Adjustable feet (yes/no)	No
Castors information	N/A
Cushion included (yes/no)	No
Cushion removable cover (yes/no)	N/A

Materials

Main material	Solid wood
Frame construction	Solid wood
Main finishing	Lacquered
Seat material details	Mungur wood (Albizia Saman)
Backrest material details	N/A
Armrest material details	N/A
Fabric type & specifications	N/A
Fabric composition	
Fabric grammage (g/m2)	
Upholstery fill material	N/A
Foam density (kg/m3)	
Legs material	Mahogany wood (Swietenia macrophylla)
Legs finishing	Lacquered in NC (Nitrocellulose)
Feet pad type	No
Cushion fabric type	N/A
Cushion fabric composition	
Cushion grammage (g/m2)	
Cushion fill material	N/A
Cushion thickness (cm)	

Assembly

Unpacking time (min)	3
Assembly required (yes/no)	No
Difficulty of assembly	N/A
People required	
Assembly time (min)	
Assembly suggestions	This does not apply to the product

Assembly instructions

Care & Warranties

General warnings	Do not use abrasive products like acetones, bleaches, solvents, etc. To extend the durability of wooden outdoor furniture please follow the specific care instructions.
Specific use and care instructions	Clean with a mild soapy solution and dry immediately. We strongly recommend varnishing/re-staining the furniture regularly once a year to prevent dryness, cracks and moisture absorption.
Specific use and care instructions for outdoor	Store the furniture in a dry indoor place. If you want to leave it outdoors, protect it with a waterproof cover in autumn, winter and rainy season.
Years of guarantee	2
Made according to	EN 12520:2015 for household use seats
FSC certified (yes/no)	No
PEFC certified (yes/no)	No
FLEGT license (yes/no)	Yes
Variation type	Natural wood grain and/or Colour tone
Purposeful distressing type	Coat & Paint distressing
Additional information	Wood origin country: Indonesia

Packaging

Units per lot					
Cbm (m3) / Gross weight (Kg)	0,06	/	4,5		
Nº of boxes	1				
Box 1	1				
Description	CROSBY Footrest wood teak				
Description box	FULL ITEM				
Height x Width x Depth (cm)	49	x	35	x	35
Cbm (m3) / Gross weight (Kg) / Net weight (Kg)	0,060	/	4,5	/	3,5
Box 2					
Description					
Description box					
Height x Width x Depth (cm)		x		x	
Cbm (m3) / Gross weight (Kg) / Net weight (Kg)		/		/	
Box 3					
Description					
Description box					
Height x Width x Depth (cm)		x		x	
Cbm (m3) / Gross weight (Kg) / Net weight (Kg)		/		/	